nforts of Home Services, Inc.

TRAILER OPERATIONS MANUAL

Read and follow all directives in this manual during each operation of the unit to ensure safety for the operator and users. Failure to adhere to the proper procedures can result in unit malfunction and damage to occupants, operators, or the unit itself.

If you have additional questions that cannot be answered after reading through this manual, please don't hesitate to call or email us.

(630-906-8002, info@cohsi.com)

Properly maintaining and operating your trailer will ensure peak performance of the unit for years to come.

TABLE OF CONTENTS

IMPORTANT SERVICE NUMBERS	1
FRESH WATER AND PUMP OPERATION	2
WASTE TANK	4
ELECTRICAL	6
WATER HEATER	7
GAS/PROPANE WATER HEATER	8
WASHER AND DRYER	9
ADDITIONAL TRAILER COMPONENTS	10
WINTERIZING	11
HYDRAULICS AND HANDICAP ACCESSIBLE LOWERING POD	12
HYDRAULIC LOWERING OPERATIONS	13
ELECTRIC LOWERING TRAILER OPERATION	14
HANDICAP ACCESSIBLE SHOWER DRAIN LEVELING	15
HANDICAP ACCESSIBILITY RAMP	16
TRANSPORTING YOUR TRAILER	17
HANDICAP ACCESSIBLE LOWERING ROOM TRANSPORT	18
TRAILER SET-UP TIPS	19
TRAILER MAINTENANCE TIPS	20
TRAILER MAINTENANCE	21
SLOAN CLEANING & CARTRIDGE CHANGING	22
TIRE SAFETY INFORMATION	23
COMFORT CARE WARRANTY	26
TERMS & CONDITIONS	27
INVENTORY LISTS	30
QUICK REFERENCE GUIDE	31

IMPORTANT SERVICE NUMBERS

• COHSI • 630-906-8002

• Dometic (A/C units) • 800-544-4881

- Takagi (Propane water heater) 877-737-2840
 - Dexter Axle 574-295-7888
 - Saniflo (Grinder toilet) 732-225-6070

Additional manuals and warranty information are available on our website: www.cohsi.com

FRESH WATER AND PUMP OPERATION

(TYPICAL UTILITY ROOM LAYOUT)

1: The 1st valve in the sequence is located inside the utility room door and is to be opened when filling the water tank or running on fresh water (hose hookup). Valve must be closed when running the pump.

2: The 2nd valve is only opened when filling the tank. It is left closed all other times.

3: The 3rd valve is typically located behind pump and must be open to use the pump. Valve must be closed only when filling tank or operating on a fresh water source (hose hookup)

4: The 4th valve is on the front side of the pump; this valve must be open when pump is being used but closed when filling tank, winterizing, and running on fresh water.



FRESH WATER AND PUMP OPERATION

(TYPICAL UTILITY ROOM LAYOUT)

The fresh water hookup is located on the exterior of the trailer, and is used to fill the tank or when operating on a direct water source. This fitting accommodates a standard ³/₄" garden hose. Flush the hose before connecting to remove any contaminants.

1: If equipped with a fresh water tank, emptying the tank can be accomplished by opening this valve.

2: The fresh water tank (if equipped) is located inside the utility room. The tank is filled with a hose hookup on the exterior of the trailer. There is an overflow drain installed on the top of the tank. Marker lines on the tank indicate the volume of water in gallons held inside.



WASTE TANK

If equipped, the waste tank(s) is located under the floor in the belly of the trailer. Depending on size, your trailer may have one or more tanks interconnected to maximize storage capacity. **Each tank has it's own dump valve marked by a sticker on the side of the trailer**. If you are unsure of the size of your tank, please contact the manufacturer.

1: The waste water dump valve is typically located underneath trailer close to the edge of the frame (in some cases, it may be on the side).

There is one valve per waste tank. Every dump valve must be pumped when emptying the trailer. Remove the cap and open the valve to release waste from the tank. A standard valve that all pumping companies are familiar with is used.

Your trailer may have been ordered with a waste tank heating element. If equipped, this system can be turned on by plugging the heat tape into the outlet located in the utility room. This system will warm the tank to prevent the liquid inside from freezing.

2: This is the waste tank sight glass. Located on the side or front of the trailer, underneath a cover. When waste water reaches the top of the sight, the waste tank is 80% full. Monitor your tank level closely to prevent over-filling.

DO NOT TRAVEL WITH WASTE TANKS FULL.



WASTE TANK MONITOR

Your unit may be equipped with a SCAD waste tank monitor. This device has been factory calibrated to display waste tank level from Empty to Full. To function, trailer must be on level ground and plugged into shore power.

Tank level is displayed by pressing and releasing the "1" button on the monitor. If the tank is full, the LED light by the "F" will be flashing. This device is meant to give a good estimate of tank level but should not be relied on completely. A good secondary check procedure is to visually observe waste tank level through the foot pedal flush toilets.

Should your device ever come out of calibration, call the manufacturer at: 336-793-2003

for directions on how to re-set calibration. Be sure tank is emptied before calling.



ELECTRICAL

(TYPICAL ELECTRICAL ROOM SET-UP)

Each trailers electrical systems are designed unique to that trailer. Hook-ups match what was ordered, or needed for that particular trailer. There are however similar aspects to each design. Every set up either has or may have:

- A power supply hookup generally located on the exterior near the utility door
- A box of outlets used for the various plugs located in the utility room
- Fuses for a 12V system (if equipped)
- Switches for the exterior and/or interior lights
- A fuse box labeled for what each fuse controls

If using multiple 110V plugs, each must be connected to a separate dedicated power source.

If you have questions on your electrical set up, please contact the manufacturer.



WATER HEATER

(IF EQUIPPED)

If your trailer is equipped with a water heater, it will need to be plugged into an electrical outlet for operation. Once plugged in, the desired temperature is set via the dial on the unit. Do not turn the water heater on unless the unit is filled with water. Operating the water heater without water will damage the unit and void the warranty.

The water heater may have a valve bypass system installed. Valves on either side of the unit control water flow into, and out of the heater. Both must both be open to use the water heater, or closed when not in use. The upper middle valve is the water heater bypass. Open this valve with the other two closed to bypass the water heater. Keep this valve closed to use the water heater.

When winterizing the trailer, open the top bypass valve and close the two side valves. This will allow antifreeze to flow past the heater effectively shutting off the water supply to the heater. Once bypassed, unscrew the lines from the top of the heater and remove it. After it is removed from the trailer, empty the water out of the heater and store for the winter in a heated environment. If equipped with an on demand water heater, drain the hot and cold sides of the unit by either unscrewing the fittings below the unit or unscrewing the drain and filter on the bottom of the unit.



Water Heater bypass valve
Hot water line valve
Cold Water Line Valve

WATER HEATER

(IF EQUIPPED PT. 2

If the trailer is equipped with a gas/propane water heater, the following applies:

The water heater must be connected to the fuel source and plugged into an operating electrical outlet to be used. Use the interface on the front of the unit or the detached thermostat depending on the model, to set the temperature. Do not operate heater without water in the system, operating the water heater without water will damage the unit and void the warranty.

IMPORTANT:

Be sure to check the ducting on the top of the heater unit, and remove any debris or obstructions from the exterior vent port. The ducting should be tight and not allow any flow of exhaust gases back into the trailer. The ducting should be rechecked before each operation. There will be a carbon monoxide detector near the heater unit, the detector must be checked periodically for function and battery life.

To winterize the heater unit, pump antifreeze into water lines, opening any valves necessary to allow antifreeze to flow into the unit. Once the water system is filled with antifreeze, open the check valve on the heater unit to empty content. Be sure to completely flush the heater of antifreeze before operating again.



- 1: Propane fittings
- 2: Condensate/Pressure Relief Drain
- 3: Cold Water In
- 4: Hot Water out
- 5: Pressure Relief Valve

KNOW THE TYPE GAS REQUIRED FOR ALL APPLIANCES IN YOUR TRAILER BEFORE OPERATING (PROPANE(LP) OR NATURAL GAS(NG))

Notice: Before turning on gas (NG or LP), make certain all gas connections have been made tight, all appliance valves are turned off, and any unconnected outlets are capped After turning on gas, test gas piping and connections to appliances for leakage with a soapy water or bubble solution and light all pilots if equipped.

Before Turning on LP gas be certain appliances are designed for LP gas and are equipped with the correct orifices. Securely cap this inlet when not in use. Regulator must be rated for at least 500,000BTU.

WASHER AND DRYER

If the trailer is equipped with washer and dryer units, the following applies:

All fittings on washers and dryers must be checked prior to each operation. These fittings are located on the rear of the units.

The washer and dryer units will be secured using bracing on the top and rear of the units. This bracing should be inspected before each travel or use of the units. The bracing will keep units tight and secure with no movement. If necessary, replace the bracing.

Most washer units will come with travel bolts in place to lock the drum to prevent damage during the initial delivery travel. These bolts must be removed prior to the first use of the unit. They do not need to be replaced.

IMPORTANT: Be sure to inspect the dryer venting before each operation of the unit. The dryer venting should not allow any exhaust fumes to escape into the trailer and should be checked for obstructions prior to use. The venting should also be periodically vacuumed out to remove lint and other obstructions as part of a maintenance schedule. There will be a carbon monoxide detector inside the laundry room with the units, the detector must be checked periodically for function and battery life.



ADDITIONAL TRAILER COMPONENTS

With most trailers, the A/C unit will be mounted on the roof of the trailer. The controls for the unit will be on an interior ceiling panel, located underneath where the unit is mounted or with thermostat. Dials on the unit control the fan speed and temperature, and are adjustable to your desired setting. Power to the unit is turned on/off via the breaker in the fuse box of the trailer. Additional operating directions can be found in the AC owners manual provided with your unit.

A battery may be installed to run various 12V components of the trailer. The charge of the battery is maintained by either a transformer, or a separate charger. If the battery is not holding a charge, the connections to the charging device should first be checked.

For trailers with powered vents installed, operate the vents by turning the dial to the desired speed setting (manufacturer recommends leaving it set to #1). The roof vent must for open for the fan motor to run .

For trailers with propane accessories installed, frequently check propane levels in the tanks and fill when necessary. For operating propane fueled accessories, refer to the provided manufacturers manual.



WINTERIZING

When a trailer is to be subjected to freezing temperatures, it must be winterized or properly heated to prevent damage. Below is the recommended procedure for winterizing the trailer:

- 1. Drain remaining water from waste and fresh water tanks
- 2. Disconnect any fresh water hoses currently hooked up to the trailer. Open the valve inside the utility room just behind the fresh water inlet, close tank fill valve, and open both pump valves.
 - i. Run pump until water stops coming out of the unit through the hose hookup.
 - ii. Once water stops, close both valves next to the pump, unhook the water lines going into the pump, and run the pump dry
- **3.** Hook up an antifreeze pump to water hookup on trailer and pump antifreeze into water lines.
- 4. Go through each room and run each fixture until antifreeze is seen.
- 5. Pour extra antifreeze into p-traps and shower drains
- 6.Wipe excess antifreeze from fixtures to avoid staining and residue
- 7. Vacuum out antifreeze from residential toilets or Saniflo[®] pumps if applicable.
 - i. To winterize residential/Saniflo[®] toilets, open valve and allow holding tank to fill with antifreeze
 - **ii.** Once the tank is full, shut the valve, then flush the toilet
 - a) For Saniflo[®] toilets, make sure the breaker for the Saniflo[®] grinder is engaged, and allow it to run before shutting off
 - iii. Vacuum excess antifreeze left in toilet bowl and holding tank
 - a) For Saniflo[®], open the drain by twisting the drain cap and pulling
 - **b**) Using a screw driver or other long narrow device, push into the drain to let the antifreeze flow out of the Saniflo[®].
 - c) Replace the drain cap and twist closed.
- 8. After all fixtures have been winterized, open the tank fill valve, and run antifreeze into the fresh tank until it passes the tank drain, and flows out
- i. Open the fresh tank dump valve and leave open
- **9.** If the trailer is equipped with a water heater, refer to the water heater page provided for details on winterizing

HYDRAULICS AND HANDICAP ACCESSIBLE LOWERING POD

Your trailer is equipped with an Handicap Accessible Lowering Pod. The hydraulic control system installed to raise and lower the pod is located in the utility room. The pump is operated using the Lift Control Lever located on the front of the pump. The pump is powered by a battery installed in the utility room. This battery is fuse protected with a Thermal Circuit Breaker Switch installed on the wall above the pump. The battery must be fully charged, or the pump will not operate. Once lowered, the Handicap Accessible pod must be leveled for the door to operate correctly. This will need to be done with shims under the feet. Do not walk on the ramp while the pod is raised. The increased angle of the ramp while the box is raised puts additional stress on the ramp welds.

- 1: Thermal Circuit Breaker Switch
- 2: Lift Control Lever
- 3: Hydraulic Oil Reservoir



HYDRAULIC LOWERING OPERATIONS

To lower frame:

- **1.** Raise frame to full height by lowering front and rear hydraulic jacks via included controller (diagram below).
 - i. The controller is located inside of the hydraulic motor box.
 - **ii.** Flip the middle switch to extend, then activate either the front or rear jacks by engaging the labeled buttons on the controller.
 - **a)** Only engage 2 jacks at a time (generally front or rear together) to ensure stability and equal rising of the jacks.
 - **iii.** Once the switch is flipped, and the jacks activated, hold the middle (unit activation) button to set the jacks in motion.
 - **iv.** When raising and lowering, level the trailer in stages middle goes down bit, then the front. Deactivate and reactivate the jacks in stages as the trailer raises.
- 2. Once the pressure is off the leaf springs, pull the Red handle hitch pins from each mount. There will be one pin per wheel.
 - i. Place the pins in secondary hole in mount to avoid binding of the mount and leaf spring.
- 3. Lower the frame to the ground by raising the jacks.
 - i. Flip the center switch to retract to lower the jacks.
 - ii. Lower the trailer in stages to avoid stress and damage to the unit.
- 4. Repeat this process in reverse to raise the trailer .
- **5.** A tell tale sign that the trailer was not lowered or raised in level stages (front a little, back a little, etc) or on level surfaces is a bent hydraulic jack. Take care to prevent this from happening, as a bent jack will not be covered under warranty.
- 6. Jacks must be fully retracted for travel.



ELECTRIC LOWERING TRAILER OPERATION



To lower frame:

- **1.** Raise frame to full height by lowering front and side jacks..
 - i. The control switch for the front jack is located on jack itself.
 - **ii.** Controls for the side jacks are located in the utility room on the orange wand.
- 2. Once the pressure is off the leaf springs, pull the Red handle hitch pins from each mount. There will be one pin per wheel.
 - **i.** Place pins in secondary hole in the mount to avoid binding of mount and leaf spring.
- **3.** Lower the frame by raising the jacks.
- 4. Repeat this process in reverse to raise the trailer.
- **5.** When raising and lowering, level the trailer in stages middle goes a down bit, then the front.

Before transporting, double check to make sure hitch pin is in place with the cotter pin fully secure in place. Also, check to make sure the ramp is up, and the ramp locking pins are fully engaged.

HANDICAP ACCESSIBLE SHOWER TRAILERS

If your trailer is equipped with a handicap accessible shower, special steps may need to be taken to ensure proper draining in the handicap shower bay. In all likleyhood, the trailer is not sitting on level ground. This may cause water to pool on the opposite side of the shower drain. To counteract this, using the jacks (or shims under the wheels if not a lowering trailer) angle the trailer so that the drain side is slightly lower than the non-drain side. See diagram below for an example on how you would level this particular unit.



HANDICAP ACCESSIBLITY RAMPS

- **1.** Trailer or pod must be in it's fully lowered and leveled position
- **2.** Mounting hardware attaching ramp to trailer must be verified tight, secure and free of visible corrosion
- 3. Ramp must be clean and dry. Do not use the ramp in wet conditions.
- **4.** Railings must be installed and secured in place. Frequently inspect railings for corrosion or other metal fatigue on the grab rails.

DO NOT USE WITHOUT RAILINGS IN PLACE.

- 5. Front edges of ramp need to be guarded to prevent a trip hazard.
- **6.** Inspect door latch and catch daily to ensure proper operation. Door closure needs to be frequently adjusted for proper closing and opening force
- 7. Locking pins that hold ramp up during travel need to be inspected for corrosion and to ensure the fasteners holding latch to trailer are secure
- **8.** An on-site attendant should be present to assist patrons using the handicap accessible room.



WARNING

2 OPERATORS ARE REQUIRED TO LOWER THE RAMP. VERIFY NO ONE, INCLUDING THE RAMP'S OPERATORS, ARE UNDER OR NEAR THE RAMP BEFORE DISENGAGING THE LOCKING PINS AND LOWERING TRAILER OR BOX MUST BE IN IT'S FULLY LOWERED POSITION BEFORE LOWERING THE RAMP. FIRMLY HOLD RAMP AGAINST TRAILER WHILE DISENGAGING PIN, THEN SLOWLY LOWER THE RAMP TO THE GROUND.

TRANSPORTING YOUR TRAILER

To prevent damage to your trailer, and to ensure your safety

and that of others on the road, we recommend the following steps be taken prior to transporting your trailer.

1. Empty the water and waste tanks. Do not tow with a full waste tank.

2. Close all toilet lids and vents. Secure all partition and cabinet doors by applying a low-tact "painters" tape to ensure locks stay engaged, doors stay shut, and drawers don't slide open.

3. Disconnect all electrical and water hook-ups.

4. Secure any loose items on the floor in a fashion that will prevent them from sliding and damaging the trailer interior.

5. Lock the entry doors and close. Place handrails in transport position and tighten the nut. If necessary use protection on the handrails to avoid damaging the door frame.

6. Secure the steps by flipping bottom stairs up onto themselves. With slide-out steps, push the stairs in and engage pin latches.

7. If a Handicap Accessible Ramp is installed, raise the ramp and secure using the latches mounted to the trailer.

8. Check and tighten tire lugs to proper torque. Frequently check the pressure in tires is at the manufacturers recommended level. Check for wear and damage to tires, replace as necessary.

9. Raise leveling jacks around trailer.

10. Hook the trailer to the transport vehicle. A 2 -5/16" ball with properly sized hitch assembly is required. Make sure the top of the ball is at the proper height to tow the trailer level. Load leveling hitches are recommended for safely dispersing the load to the front tires of the tow vehicle on heavier trailers.

See tow vehicle manual and www.safercar.gov for guides.

11. Attach safety chains and plug in a 7 way wire trailer cable to the receptacle on the vehicle.

Check that the tow vehicle fuses are intact, and ensure that all trailer lighting is functioning properly. Attach emergency break-away cable to the vehicle, leaving enough slack to avoid accidental break engagement. Test trailer brakes using tow vehicles brake controller before going on the road.



HANDICAP ACCESSIBLE LOWERING ROOM TRANSPORT

On all Handicap Accessible lowering pod trailers, 2 safety straps are provided for transport.

These straps must be in place whenever the pod is raised and the trailer is in transport.

To operate while the room is lowered:

- 1. Close and lock the entry door
- 2. Raise the ramp and secure using latches
- 3. Raise Handicap Accessible room to full height
- 4. Hook straps onto the D-rings welded to Handicap Accessible room and main trailer
- **5.**Use the ratcheting system on safety straps to tighten

6.Cut off power to the hydraulic pump by tripping the thermal fuse located above the pump





TRAILER SET-UP TIPS

Make sure the trailer is on level ground. An unleveled trailer can cause falls and reduced capacity of the waste tank(s). Lower all leveling jacks (half turn after initial contact with the ground). Plywood or another other material may be needed underneath the feet of the jacks if ground is soft.

Power up trailer with the required number of power cords heavy enough for the amps it will carry and the distance it runs. See an electrician to be sure the proper cords are used. Usually a 10 gauge cord is heavy enough for 20amps for 100 feet.

**This is critical that the power supply is dedicated for each cord from the fuse panel as any other load on that breaker will cause the breaker to trip.

Long runs may require heavier cables and a larger breaker. Consult an electrician for proper sizing. Improper cords will cause the cord to get hot, may cause a fire and may cause the circuit to trip.

Before connecting a garden hose to the trailer, be sure it is flushed out to remove any contaminates. For shower trailers, turn on the gas supply before turning on the power, check for gas leaks each time. Over time or after changing a tank the gas lines may have air in them at which point you will need to flush the line with gas by opening the purge port at the bottom of the heater if equipped or loosen the nut for 20 seconds below the heater.

TRAILER MAINTENANCE TIPS

TRAILER FRAME

Road use and natural elements will wear away at the protective paint on your frame. Keeping the frame painted and rust free will not only keep your trailer looking nice, but will prevent rust from damaging the steel. A high gloss black Rust-o-leum paint is the best product to use for touch ups.

EXTERIOR ALUMINUM SKIN

Keep the exterior clean by frequent washings. Exterior aluminum cleaning products can be purchased at an RV store. Seasonal waxing will keep a high gloss finish on the skin, and will prevent dirt from sticking.

ROOF

Frequently inspect the roof. If a hole is found, it can be sealed using an exterior grade silicon caulk

DOORS

Keep door hinges lubricated. Frequently inspect door locks and lock catches for proper operation.

INTERIOR CLEANING

Keeping a clean interior not only extends the life of your trailer, but shows users you care about their comfort while using your trailer. Never use pressure a washer inside a trailer. Clean inside of trailer like you would clean your house. If you have a wash down interior, (rubber floor and/or caulked aluminum trim with linoleum) you can use a commercial heavy mop and bucket.

FIXTURE CLEANING

NEVER DUMP WATER INTO THE URINALS. This will flush the chemical out of the canister, which will in turn cause a urine smell to arise in the Men's room. Simply wipe out the urinals with a mild cleaning detergent and follow cleaning instructions included with Falcon Water Free Urinals.

- Clean toilet flush ball seals.
- Clean A/C intake screens.
- Clean water inlet, garden hose intake fitting screen.
- Clean faucet aerators.
- Clean the faucet screen located in the supply hose where it attaches to the water valve.
- Put the hose back on hand tight plus just a quarter turn to avoid damaging the filter and seal.
- Replace the Urinal Cartridge and oil every 6 months to a year depending on use.

PLUMBING AND ELECTRICAL

Frequently inspect water and drain lines in the utility room. Look for any leaks or corrosion on the fittings. Check under sinks and toilets inside the trailer. Make sure supply lines and sink drains are tight.

TRAILER MAINTENANCE

ALUMINUM TRIM

Your trailer has aluminum components on the exterior. Doors, trim, and rims should all be frequently polished to not only keep the trailer looking sharp, but also to prevent corrosion.

WASTE TANK

Frequently flushing out the waste tank is a good practice to keep your tank smelling fresh. Filling the tank about ¼ full and driving around the block will break up any solids stuck in the tank. RV tank chemicals may be added in accordance with the manufacturers application directions.

PUMPING THE TRAILER

The easiest way to pump the trailer is by inserting a standard 2" PVC portable toilet wand down the toilet flushing hole. You will have to pump thru a toilet from each tank to evacuate all tanks, usually the front most and rear most toilets will do. For a trailer larger than 28' you may have 3 tanks so a center toilet will need to be pumped as well. Start from the top of the tank and work your way to the bottom to collect the solids first to insure everything flows towards you. Multiple tanks are connected together towards the top of the tank. If using the onboard sewage pump, hook the 1.5" line coming out of the trailer in front of the passenger side tire to a sewer system. Run the sewer pumps as necessary to empty the waste tanks, there is a switch for each pump which services on tank each. If trailer is equipped with a fresh water tank, start draining the tank ASAP. Tanks shouldn't be hauled with fluid in them

TRAILER BRAKES

Your trailer brakes should be inspected and / or serviced every few thousand miles. The heavier the trailer and the more you transport it, the quicker the brakes will wear our. The trailer braking system is a very important element of your safety while on the road.

TIRES AND WHEELS

Over time, the lug nuts on your trailer can become loose. Every few hundred miles and before any long road trips, be sure to tighten the lug nuts to 90 foot pounds using a torque wrench. The same frequency is recommended for checking tire pressure. Do Not adjust tire pressure for the load of the trailer. Grease axle joints and bearings every 5,000 miles.

INSTALLING INTERIOR ACCESSORIES

Interior accessories such as toilet paper holders, soap dispensers and pictures may be installed in your unit. Remember, once you put a hole in the wall, there is no going back. Follow the "measure twice, drill once" rule. All trailer walls are made of $\frac{1}{2}$ " plywood. For mounting accessories, use no screw LARGER THAN $\frac{3}{4}$ ". Our recommendation is to use the screws provided with your trailer $-\frac{3}{4}$ " drywall screws.



CLEANING AND CARTRIDGE CHANGING INSTRUCTIONS

URINAL BOWL CLEANING INSTRUCTIONS



Spray (mist) cleaner on the entire bowl.



Clean outside and inside of bowl with rag or sponge.

Clean the entire outside and inside of bowl with mop.

OR

WHEN SHOULD A CARTRIDGE BE CHANGED?





Fluid flows very slowly into the cartridge

З



Blue sealant appears on top of the cartridge

CARTRIDGE CHANGING INSTRUCTIONS



Insert key into cartridge.



CAUTIONAfter removing cartridge from housing, certain naturally occurring but potentially hazardous sewer gases may escape through the opening until

may escape through the opening until re-installed properly. If replacement cartridge will not be re-installed into opening to block any sever gases. Remove the paper towels or rag prior to inserting new cartridge. Never smoke, have an open flame, or place your nose or mouth near waterless urinal housings into which a cartridge is not yet properly installed. You also can wear a breathing mask when removing or installing any waterless urinal or cartridge to reduce potential exposure to any such gases.



Insert new cartridge into housing and turn key to right to lock and click into place.



5

Slowly fill cartridge with 1 quart (1 liter)

or more of clean water until there are

Turn key to left to unlock.

9

no air bubbles.



sealant and urine).



Scrub the housing and deep inside of the tail-Flush housing with 5 gallons pipe with a long 1.5-inch diameter nylon brush. (20 liters) of hot soapy water.



Add blue sealant (allow time to drain into Spray (mist) cleaner and wipe clean. cartridge).



Place cartridge into bag, tie bag to seal and dispose.



Wipe clean inner stainless steel rim.



TIRE SAFETY INFORMATION

1.3. GLOSSARY OF TIRE TERMINOLOGY:

Accessory weight The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not).

Bead The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim. Bead separation This is the breakdown of the bond between components in the bead.

Bias ply tire A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread.

Carcass The tire structure, except tread and sidewall rubber which, when inflated, bears the load. Chunking The breaking away of pieces of the tread or sidewall.

Cold inflation pressure The pressure in the tire before you drive. Cord The strands forming the plies in the tire.

Cord separation The parting of cords from adjacent rubber compounds.

Cracking Any parting within the tread, sidewall, or inner liner of the tire extending to cord material. CT A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire.

Curb weight The weight of a motor vehicle with standard equipment including the maximum capacity of fuel, oil, and coolant, and, if so equipped, air conditioning and additional weight optional engine. Extra load tire A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire

Groove The space between two adjacent tread ribs.

Gross Axle Weight Rating The maximum weight that any axle can support, as published on the Certification / VIN label on the front left side of the trailer. Actual weight determined by weighing each axle on a public scale, with the trailer attached to the towing vehicle.

Gross Vehicle Weight Rating The maximum weight of the fully loaded trailer, as published on the Certification / VIN label. Actual weight determined by weighing trailer on a public scale, without being attached to the towing vehicle. Hitch Weight The downward force exerted on the hitch ball by the trailer coupler.

Innerliner The layer(s) forming the inside sufficiency of a tubelless tire that contains the inflating medium within the tire. Innerliner separation The parting of the innerliner from cord material in the carcass. Intended outboard sidewall The sidewall that contains a white-wall, bears white lettering or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the

other sidewall of the tire or the outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle. Light truck (LT) tire A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles.

Load rating The maximum load that a tire is rated to carry for a given inflation pressure.

Maximum load rating The load rating for a tire at the maximum permissible inflation pressure for that tire. Maximum permissible inflation pressure The maximum cold inflation pressure to which a tire may be inflated.

Maximum loaded vehicle weight. The sum of curb weight, accessory weight, vehicle capacity weight, and production options weight.

Measuring rim The rim on which a tire is fitted for physical dimension requirements.

Pin Weight The downward force applied to the 5th wheel or gooseneck ball, by the trailer kingpin or gooseneck coupler

Non-pneumatic rim A mechanical device which, when a non-pneumatic tire assembly incorporates a wheel, supports the tire, and attaches, either integrally or separably, to the wheel center member and upon which the tire is attached.

Non-pneumatic spare tire assembly A non-pneumatic tire assembly intended for temporary use in place of one of the pneumatic tires and rims that are fitted to a passenger car in compliance with the requirements of this standard.

Non-pneumatic tire A mechanical device which transmits, either directly or through a wheel or wheel center member, the vertical load and tractive forces from the roadway to the vehicle, generates the tractive forces that provide the directional control of the vehicle and does not rely on the containment of any gas or fluid for providing those functions. Non-pneumatic tire assembly A non-pneumatic tire, alone or in combination with a wheel or wheel center member, which can be mounted on a vehicle

Normal occupant weight This means 68 kilograms (150 lbs.) times the number of occupants specified in the second column of Table I of 49 CFR 571.110. Occupant distribution The distribution of occupants in a vehicle as specified in the third column of Table I of 49 CFR 571.110.

Open splice Any parting at any junction of tread, sidewall, or innerliner that extends to cord material.

Outer diameter The overall diameter of an inflated new tire. Overall width The linear distance between the exteriors of the sidewalls of an inflated tire, including elevations due to labeling, decorations, or protective bands or ribs.

Ply A layer of rubber-coated parallel cords.

Ply separation A parting of rubber compound between adjacent plies.

Preumatic tire A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load.

Production options weight The combined weight of those installed regular production options weighing over 2.3 kilograms (5 lbs.) in excess of those standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim

Radial ply tire A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread. Recommended inflation pressure This is the inflation pressure provided by the vehicle manufacturer on the Tire Information label and on the Certification / VIN tag.

Reinforced tire A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire.

Rim A metal support for a tire or a tire and tube assembly upon which the tire beads are seated.

Rim diameter This means the nominal diameter of the bead seat.

Rim size designation This means the rim diameter and width. Rim type designation This means the industry of manufacturer's designation for a rim by style or code.

Rim width This means the nominal distance between rim flanges.

Section width The linear distance between the exteriors of the sidewalls of an inflated tire, excluding elevations due to labeling, decoration, or protective bands.

Sidewall That portion of a tire between the tread and bead.

Sidewall separation The parting of the rubber compound from the cord material in the sidewall. Special Trailer (ST) tire The "ST" is an indication the tire is for trailer use only.

Test rim The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire.

Tread That portion of a tire that comes into contact with the road. Tread rib A tread section running circumferentially around a tire.

Tread separation Pulling away of the tread from the tire carcass. Treadwear indicators (TWI) The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread.

Vehicle capacity weight The rated cargo and luggage load plus 68 kilograms (150 lbs.) times the vehicle's designated seating capacity.

Vehicle maximum load on the tire The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight and dividing by two. Vehicle normal load on the tire The load on an individual tire that is determined by distributing to each axle its share of the curb weight, accessory weight, and normal occupant weight (distributed in

accordance with Table I of CRF 49 571.110) and dividing by 2. Weather side The surface area of the rim not covered by the inflated tire.

Wheel center member In the case of a non-pneumatic tire assembly incorporating a wheel, a mechanical device which attaches, either integrally or separably, to the non-pneumatic rim and provides the connection between the non-pneumatic rim and the vehicle; or, in the case of a non-pneumatic tire assembly not incorporating a wheel, a mechanical device which attaches, either integrally or separably, to the non-pneumatic tire and provides the connection between tire and the vehicle.

Wheel-holding fixture The fixture used to hold the wheel and tire assembly securely during testing.

1.4. TIRE SAFETY - EVERYTHING RIDES ON IT

The National Traffic Safety Administration (NHTSA) has published a brochure (DOT HS 809 361) that discusses all aspects of Tire Safety, as required by CFR 575.6. This brochure is reproduced in part below. It can be obtained and downloaded from NHTSA, free of charge, from the following web site:

http://www.nhtsa.dot.gov/cars/rules/TireSafety/ridesonit/tires index.html

Studies of tire safety show that maintaining proper tire pressure, observing tire and vehicle load limits (not carrying more weight in your vehicle than your tires or vehicle can safely handle), avoiding road hazards, and inspecting tires for cuts, slashes, and other irregularities are the most important things you can do to avoid tire failure, such as tread separation or blowout and flat tires. These actions, along with other care and maintenance activities, can also:

Improve vehicle handling

Help protect you and others from avoidable breakdowns and accidents

Improve fuel economy

Increase the life of your tires

This booklet presents a comprehensive overview of tire safety, including information on the following topics: Basic tire maintenance

Uniform Tire Quality Grading System

Fundamental characteristics of tires

Tire safety tips.

Use this information to make tire safety a regular part of your vehicle maintenance routine. Recognize that the time you spend is minimal compared with the inconvenience and safety consequences of a flat tire or other tire failure

TIRE SAFETY INFORMATION

1.5. SAFETY FIRST-BASIC TIRE MAINTENANCE

Properly maintained tires improve the steering, stopping, traction, and load-carrying capability of your vehicle. Underinflated tires and overloaded vehicles are a major cause of tire failure. Therefore, as mentioned above, to avoid flat tires and other types of tire failure, you should maintain proper tire pressure, observe tire and vehicle load limits, avoid road hazards, and regularly inspect your tires.

1.5.1. FINDING YOUR VEHICLE'S RECOMMENDED TIRE PRESSURE AND LOAD LIMITS

Tire information placards and vehicle certification labels contain information on tires and load limits. These labels indicate the vehicle manufacturer's information including

- Recommended tire size
- Recommended tire inflation pressure

Vehicle capacity weight (VCW-the maximum occupant and cargo weight a vehicle is designed to carry)

Front and rear gross axle weight ratings (GAWR- the maximum weight the axle systems are designed to carry). Both placards and certification labels are permanently attached to the trailer near the left front.

1.5.2. UNDERSTANDING TIRE PRESSURE AND LOAD LIMITS

Tire inflation pressure is the level of air in the tire that provides it with load-carrying capacity and affects the overall performance of the vehicle. The tire inflation pressure is a number that indicates the amount of air pressure- measured in pounds per square inch (psi)-a tire requires to be properly inflated. (You will also find this number on the vehicle information placard expressed in kilopascals (kpa), which is the metric measure used internationally).

Manufacturers of passenger vehicles and light trucks determine this number based on the vehicle's design load limit, that is, the greatest amount of weight a vehicle can safely carry and the vehicle's tire size. The proper tire pressure for your vehicle is referred to as the "recommended cold inflation pressure." (As you will read below, it is difficult to obtain the recommended tire pressure if your tires are not cold.)

Because tires are designed to be used on more than one type of vehicle, tire manufacturers list the "maximum permissible inflation pressure" on the tire sidewall. This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions.

1.5.3. CHECKING TIRE PRESSURE

It is important to check your vehicle's tire pressure at least once a month for the following reasons:

Most tires may naturally lose air over time.

Tires can lose air suddenly if you drive over a pothole or other object or if you strike the curb when parking With radial tires, it is usually not possible to determine under inflation by visual inspection.

For convenience, purchase a tire pressure gauge to keep in your vehicle. Gauges can be purchased at tire dealerships, auto supply stores, and other retail outlets. The recommended tire inflation pressure that vehicle manufacturers provide reflects the proper psi when a tire is cold. The term cold does not relate to the outside temperature. Rather, a cold tire is one that has not been driven on for at least three hours. When you drive, your tires get warmer, causing the air pressure within them to increase. Therefore, to get an accurate tire pressure reading, you must measure tire pressure when the tires are cold or compensate for the extra pressure in warm tires.

1.5.4. STEPS FOR MAINTAINING PROPER TIRE PRESSURE

Step 1: Locate the recommended tire pressure on the vehicle's tire information placard, certification label, or in the owner's manual.

Step 2: Record the tire pressure of all tires.

Step 3: If the tire pressure is too high in any of the tires, slowly release air by gently pressing on the tire valve stem with the edge of your tire gauge until you get to the correct pressure. Step 4: If the tire pressure is too low, note the difference between the measured tire pressure and the correct tire pressure. These "missing" pounds of pressure are what you will need to add. Step 5: At a service station, add the missing pounds of air pressure to each tire that is underinflated.

Step 6: Check all the tires to make sure they have the same air pressure (except in cases in which the front and rear tires are supposed to have different amounts of pressure).

If you have been driving your vehicle and think that a tire is underinflated, fill it to the recommended cold inflation pressure indicated on your vehicle's tire information placard or certification label. While your tire may still be slightly underinflated due to the extra pounds of pressure in the warm tire, it is safer to drive with air pressure that is slightly lower than the vehicle manufacturer's recommended cold inflation pressure than to drive with a significantly underinflated tire. Since this is a temporary fix, don't forget to recheck and adjust the tire's pressure when you can obtain a cold reading.

1.5.5. TIRE SIZE

To maintain tire safety, purchase new tires that are the same size as the vehicle's original tires or another size recommended by the manufacturer. Look at the tire information placard, the owner's manual, or the sidewall of the tire you are replacing to find this information. If you have any doubt about the correct size to choose, consult with the tire dealer 1.5.6. TIRE TREAD

The tire tread provides the gripping action and traction that prevent your vehicle from slipping or sliding, especially when the road is wet or icy. In general, tires are not safe and should be replaced when the tread is worn down to 1/16 of an inch. Tires have built-in treadwear indicators that let you know when it is time to replace your tires. These indicators are raised sections spaced intermittently in the bottom of the tread grooves. When they appear "even" with the outside of the tread, it is time to replace your tires. Another method for checking tread depth is to place a penny in the tread with Lincoln's head upside down and facing you. If you can see the top of Lincoln's head, you are ready for new tires 1.5.7. TIRE BALANCE AND WHEEL ALIGNMENT

To avoid vibration or shaking of the vehicle when a tire rotates, the tire must be properly balanced. This balance is achieved by positioning weights on the wheel to counterbalance heavy spots on the wheel-and-tire assembly. A wheel alignment adjusts the angles of the wheels so that they are positioned correctly relative to the vehicle's frame. This adjustment maximizes the life of your tires. These adjustments require special equipment and should be performed by a qualified technician

1.5.8. TIRE REPAIR

The proper repair of a punctured tire requires a plug for the hole and a patch for the area inside the tire that surrounds the puncture hole. Punctures through the tread can be repaired if they are not too large, but punctures to the sidewall should not be repaired. Tires must be removed from the rim to be properly inspected before being plugged and patched.

1.5.9. TIRE FUNDAMENTALS

Federal law requires tire manufacturers to place standardized information on the sidewall of all tires. This information identifies and describes the fundamental characteristics of the tire and also provides a tire identification number for safety standard certification and in case of a recall.

1.5.9.1. Information on Passenger Vehicle Tires Please refer to the diagram below.



P The "P" indicates the tire is for passenger vehicles.

Next number. This three-digit number gives the width in millimeters of the tire from sidewall edge to sidewall edge. In general, the larger the number, the wider the tire

Next number This two-digit number, known as the aspect ratio, gives the tire's ratio of height to width. Numbers of 70 or lower indicate a short sidewall for improved steering response and better overall handling on dry pavement. R The "R" stands for radial. Radial ply construction of tires has been the industry standard for the past 20 years.

Next number This two-digit number is the wheel or nim diameter in inches. If you change your wheel size, you will have to purchase new tires to match the new wheel diameter.

Next number This two-or three-digit number is the tire's load index. It is a measurement of how much weight each tire can support. You may find this information in your owner's manual. If not, contact a M+S The "M+S" or "M/S" indicates that the tire has some mud and snow capability. Most radial tires have these markings; hence, they have some mud and snow capability.

Speed Rating The speed rating denotes the speed at which a tire is designed to be driven for extended periods of time. The ratings range from 99 miles per hour (mph) to 186 mph. These ratings are listed below. Note: You may not find this information on all tires because it is not required by law.

TIRE SAFETY INFORMATION

Tire Safety Information	
Letter Rating	Speed Rating
Q	99 mph
R	106 mph
S	112 mph
т	118 mph
U	124 mph
н	130 mph
V	149 mph
W	168* mph
Y	186* mph

* For tires with a maximum speed capability over 149 mph, tire manufacturers sometimes use the letters ZR. For those with a maximum speed capability over 186 mph, tire manufacturers always use the letters ZR

U.S. DOT Tire Identification Number This begins with the letters "DOT" and indicates that the tire meets all federal standards. The next two numbers or letters are the plant code where it was manufactured, and the last four numbers represent the week and year the tire was built. For example, the numbers 3197 means the 31st week of 1997. The other numbers are marketing codes used at the manufacturer's discretion. This information is used to contact consumers if a tire defect requires a recall.

Tire Ply Composition and Materials Used The number of plies indicates the number of layers of rubber-coated fabric in the tire. In general, the greater the number of plies, the more weight a tire can support. Tire manufacturers also must indicate the materials in the tire, which include steel, nylon, polyester, and others.

Maximum Load Rating This number indicates the maximum load in kilograms and pounds that can be carried by the tire.

Maximum Permissible Inflation Pressure This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions. 1.5.9.2. UTQGS Information

Tread wear Number This number indicates the tire's wear rate. The higher the treadwear number is, the longer it should take for the tread to we ar down. For example, a tire graded 400 should last twice as long as a tire graded 200. Traction Letter This letter indicates a tire's ability to stop on wet pavement. A higher graded tire should allow you to stop your car on wet roads in a shorter distance than a tire with a lower grade. Traction is graded from highest to lowest as "AA", "A", "B", and "C"

Temperature Letter This letter indicates a tire's resistance to heat. The temperature grade is for a tire that is inflated properly and not overloaded. Excessive speed, underinflation or excessive loading, either separately or in combination, can cause heat build-up and possible tire failure. From highest to lowest, a tire's resistance to heat is graded as "A", "B", or "C".

1.5.9.3. Additional Information on Light Truck Tires



Maximum Load & Inflation When Load Inflation Used As Single Limits Tires for light trucks have other markings besides those found on the sidewalls of passenger tires.

LT The "LT" indicates the tire is for light trucks or trailers. ST An "ST" is an indication the tire is for trailer use only.

Max. Load Dual kg (lbs) at kPa (psi) Cold This information indicates the maximum load and tire pressure when the tire is used as a dual, that is, when four tires are put on each rear axle (a total of six or more tires on the vehicle)

Max. Load Single kg (Ibs) at kPa (psi) Cold This information indicates the maximum load and tire pressure when the tire is used as a single.

Load Range This information identifies the tire's load-carrying capabilities and its inflation limits.

1.6. TIRE SAFETY TIPS

Preventing Tire Damage

Slow down if you have to go over a pothole or other object in the road.

Do not run over curbs or other foreign objects in the roadway, and try not to strike the curb when parking.

Tire Safety Checklist

Check tire pressure regularly (at least once a month), including the spare.

Inspect tires for uneven wear patterns on the tread, cracks, foreign objects, or other signs of wear or trauma.

Remove bits of glass and foreign objects wedged in the tread.

Make sure your tire valves have valve caps.

Check tire pressure before going on a long trip.

Do not overload your vehicle. Check the Tire Information and loading Placard or User's Manual for the maximum recommended load for the vehicle.

If you believe that your vehicle has a defect that could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Comforts of Home Services Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in

individual problems between you, your dealer, or Comforts of Home Services Inc.

To contact Comforts of Home Services Inc call at 847-856-8002 or 630-906-8002. Or website: <u>www.cohsi.com</u> To contact NHTSA, you may either call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153), go to http://www.safercar.gov; or write to:

Administrator

NHTSA

1200 New Jersey Avenue S.E. Washington, DC 20590

You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

WARRANTIES

COMFORT CARE WARRANTY

Comforts of Home Services Inc (warranter), of Aurora Illinois hereby provides a 5 year limited warranty on our trailer frame and a 1 year limited warranty on the trailer as a whole.

Sealant, electrical components, hydraulics, hoses, wall coverings, trim and paint are warranted for 1 year.

The warranter guarantees the product against defects in materials and workmanship. The warranty described in this agreement is in lieu of all other warranties, expressed or implied. This warranty shall apply to the retail consumer (original purchaser), as shown on the sales agreement.

Certain individual components are warranted by their respected manufacturers' warranties and therefore are excluded from the limited warranty provided by the warranter. These components include, but are not limited to; tires, wheels, axles, couplers, jacks, light fixtures, windows, doors, heaters, air conditioners, toilets, sinks, faucets, pumps, and awnings. Warranty claims must be filed with the respective component manufacturers' warranty department. Any installation fees, shipping fees, or other costs associated with the repair of the items not covered by the respected manufactures warranty are the responsibility of the trailer owner.

This limited warranty is void if the product:

- 1. Is not properly maintained.
- 2. Is neglected, abused or misused.
- 3. Is overloaded or made to perform beyond recommended specifications.

The limited warranty is also void if damage results from continued use after a suspected defect is or should have been discovered. The warranter reserves the right to make the final determination as to whether any of the above exclusions may nullify a warranty claim.

THE WARRANTY SHALL NOT PAY NOR MAKE PROVISIONS FOR:

- **1.** Service charges; towing charges; and transportation charges, which are the responsibility of the purchaser.
- 2. Loss of time, inconvenience; loss of use; rental substitution equipment; loss of revenue; or other commercial or personal loss.
- 3. Loss or damage to any and all contents.
- 4. Defacing; scratches; dents; chips; and tears, on any surface, not caused by the warranter.

Furthermore the warranter does not warranty any modification(s) made to either the interior or exterior of the product, even if damage occurs as a result of warranty claim.

Please refer to the products owner's manual, or authorized representative of the warranter, for instructions on filing a warranty claim. The provisions of the limited warranty shall be interpreted and governed pursuant to the laws of the State of Illinois.



TERMS AND CONDITIONS

1. EFFECT OF THESE TERMS AND CONDITIONS OF SALE. The following terms and conditions shall apply to all quotations, purchase orders, and order acknowledgements related to the sale of seller's goods. Seller shall not be deemed to have waived any of the following terms or conditions, even if Seller fails to object to any contrary or inconsistent provision appearing on, attached to, or incorporated by referenced in any purchase order or other document issued by Buyer. Buyer's ordering, acceptance or use of any goods of Seller shall constitute its acceptance of the following terms and conditions without modification.

2. QUOTED TERMS. All quoted terms are subject to correction at any time for clerical error, and may be modified or withdrawn by Seller, with or without notice, at any time prior to written acceptance by Buyer. All quotations shall be deemed withdrawn if not accepted in writing by Buyer within 30 days. Quoted prices are based upon information provided by Buyer, including Buyer's estimated annual use, and may be retroactively and prospectively adjusted in the event of any change in any such information. Quoted prices may also be increased at any time to reflect increases in Seller's production and material costs. All agreements and orders are subject to the written approval of an officer of the Seller.

3. PRICES. Unless otherwise agreed upon in writing by Seller, all prices, payments and references thereto shall be in U.S. Dollars. All prices are subject to adjustment to reflect material increases in the price of precious metals included within the goods. Seller reserves the right to invoice goods at prices in effect on the delivery date. Prices do not include sales taxes, use or excise taxes, import or export duties or taxes, finance fees, value added taxes, special permits or licenses, or similar charges. Buyer shall either pay such charges or provide Seller with acceptable exemption certificates. Additionally, unless otherwise agreed upon in writing by Seller, prices do not include any charges for services such as insurance, brokerage fees, or product orientation or training.

4. PAYMENT. Unless otherwise agree in writing by Seller, Seller shall have the right to issue invoices to Buyer upon readiness of goods for delivery by Seller, and all invoices shall be due and payable upon receipt unless other conditions have been agreed to in writing without regard to delays of transportation, inspection or acceptance. Should Seller deem Buyer's financial position or payment practices to be unsatisfactory, cash payment or other security may be required. If Buyer fails to meet such requirements, Seller may discontinue the production and delivery of goods to Buyer and treat such failure at any time thereafter as reasonable grounds for the lawful termination of any pending order. Interest shall accrue on any overdue payment at the rate of 1.5% per month, or at the maximum lawful rate of interest, whichever is less.

5. TITLE AND RISK OF LOSS. All goods supplied by Seller shall have marketable title, free and clear of any security interest. Lien or encumbrance of any third party. Title to the goods, and risk of loss, shall pass to the Buyer upon notice to the Buyer of readiness of the goods for delivery. Freight and shipping obligations shall have no bearing on transfer of title or risk of loss. Claims for damages or shortages attributable to the Seller must be filed with Seller within 30 days following receipt of goods or risk of loss, which occurs first, and must be accompanied by Seller's packing slip and a detailed description of the claim.

TERMS AND CONDITIONS CONTINUED

6. MODIFICATION OF ORDERS. Requests by Buyer for any modification or change of any order, including, but not limited to, any change in specifications, quantities or delivery obligations, shall be subject to Seller's written acceptance, and may result in adjustments to prices and delivery schedules.

7. CANCELLATION OF ORDERS. Any cancellation of an order shall be in writing. Buyer shall forfeit the entire deposit amount to cover Seller's costs related to design, engineering, and materials.

8. WARRANTY. SEE COMFORT CARE WARRANTY SHEET FOR MORE INFORMATION.

9. PATENT INFRINGEMENT. If a claim is asserted based on infringement of a United States patent relating to any part of the goods (other than a part based on specifications provided by Buyer). Seller, at it's expense, shall either replace or modify such part with a non-infringing part or procure for Buyer the right to use such part, provided that Seller is given a full opportunity to conduct all negotiations in respect of such claims, but in no event shall Seller have any liability, for losses arising from any use or nonuse of any infringing part. The foregoing provisions fully set forth Seller's only responsibilities, and Buyer's exclusive remedies, with respect to any infringement by any part of the goods supplies to Buyer, and SELLER EXPRESSLY DISCLAIMS ANY OTHER WARRANTY AGAINST INFRINGEMENT, WHETHER EXPRESS OR IMPLIED. Buyer shall defend and hold Seller harmless from and against any claim of infringement for any part of the goods designed or manufactured to Buyer's specifications, including the use thereof in combination with other components, materials or processes.

10. FORCE MAJEURE. In no event shall seller be liable for any non-performance, delay in performance, or any other variation from Seller's performance obligations, nor for any loss or damage to any goods supplied to Buyer, when occasioned directly or indirectly by any cause beyond the reasonable control of Seller or its suppliers, vendors, subcontractors, or other representatives or agents, including, but not limited to, communication line failures; power failures; natural disasters or acts of God; acts of criminals or a public enemy; war; riot; official or unofficial acts; contracts, regulations or restrictions of any domestic or foreign governmental agency; acts of Buyer or its employees, representatives or agents; strikes or labor difficulties; or failures, shortages, or delays in Seller's usual sources of labor or materials. Seller shall automatically be entitled to a reasonable extension of all periods of performance when delayed by any such cause.

11. INSPECTIONS. If Buyer is permitted by Seller to inspect Seller's facilities or processes, Buyer shall not photograph or make other visual or audio recording thereof.

12. ASSIGNMENT. Unless otherwise agreed upon in writing by Seller, Seller shall have the right to assign or subcontract the performance of any of its obligations under any order. Any attempted assignment by Buyer of any of its rights or obligations under any order shall be null and void in the absence of Seller's prior written consent.

13. INDEPENDENT CONTRACTOR. At all times, Seller shall be deemed an independent contractor of Buyer, and not a partner, joint venture, employee or agent of Buyer.

14. REGULATORY COMPLIANCE. Buyer shall comply with all applicable laws, regulations and rules governing good furnished by Seller, including, but not limited to, safety and health standards, environmental regulations, technical standards, and export controls.

TERMS AND CONDITIONS CONTINUED

15. DISPUTES. Buyer and Seller shall use their best efforts to resolve in an amicable manner any dispute arising connection with any order. In the event Buyer believes that Seller is not in full compliance with its obligations hereunder, Buyer shall notify Seller in writing and Seller shall take reasonable measures to remedy the alleged non-compliance within 30 days following its receipt of said notice. Any dispute which is not so settled or resolved shall, within a reasonable period, thereafter, be submitted to arbitration in accordance with the rules of the American Arbitration Association, and judgement upon the arbitrated award may be entered in any court of competent jurisdiction. Allocation of the costs of arbitration shall be determined by the arbitrator, and each party shall bear its own attorneys' fees. Unless otherwise agreed between the parties, arbitration hearings shall be held in McHenry, Illinois, USA.

16. INTERPRETATION. The terms and conditions shall be governed by and construed in accordance with the laws of the State of Illinois, including such States' Uniform Commercial Code, without giving effect to principles of conflict of laws. Whenever any conflict exists between these terms and conditions and any provision of such Uniform Commercial Code, these terms and conditions shall govern. The section headings contained herein have been inserted for convenience only and shall not be considered in interpreting any term or condition here-of. If any term or conditioned contained herein is found to be invalid or unforeseeable, it shall be deemed strick-en here from without affecting the remaining terms or conditions hereof. Seller's failure to require the performance of any term or condition hereof shall not affect Seller's right thereafter to enforce that or any other term or condition hereof.

17. NOTICE. All notices and other communications required hereunder shall be in writing and delivered e-mail, facsimile, telegram, overnight carrier, or certified or registered mail, postage prepaid, return receipt requested. Any such notice shall be deemed to have been given on the date it is received during regular office hours at the address listed on the applicable order or at such other address as the affected party may have previously designated for notices.

18. SUBSTITUTION. Seller reserves the right to change or substitute items with equal or better items. These Terms and Conditions apply for all types of business transactions including but not limited to Sales and any other use of Comforts of Home Services products. Buyer represents the paying customer for any type of business transaction and the Seller represents Comforts of Home Services for all Terms and Conditions hereto. I the undersigned understand and agree fully with these Terms and Conditions: Company Name (if applicable):

I the undersigned understand and agree fully with these Terms and Conditions:

Company Name (if applicable):_____

Print Name:_____

Signature:_____

INVENTORY LIST

COHSI TRAILER #		COHSI TRA	COHSI TRAILER #		
ITEM	MANUFACTURER	MODEL	SERIAL NUMBER		
TIRE #1					
TIRE #2					
TIRE #3					
TIRE #4					
TIRE #5					
TIRE #6					

WARNING WARNING WARNING WARNING WARNING

Daily Maintenance must be performed to ensure proper and safe operation. Failure to do so can cause injury to users, and void warranty. Maintain daily log book to confirm the below items are done on a daily basis.

DAILY MAINTENANCE PERFORMANCE CHECKLIST

- Inspect 3" waste dump valves for proper closure free of any debris. (1 per tank)
- Inspect electrical power connection to verify proper connection and safe operation.
- Ensure stairs and stair handle are secure and free of any debris.
- Inspect door handles, locks and LED indicators from both sides of door for proper operation.
- Check connections on handicap accessible ramp to confirm properly secure and free of debris.
- Inspect scissor and tongue jacks for proper operation and extension when leveling the trailer. Trailer must be kept level at all times
- Confirm that the tires are properly chocked, pressurized, and lug nuts properly tighted.
- Inspect propane tanks, lines and connections to confirm they are in safe operating condition.
- Inspect interior and exterior LED lighting to ensure proper operation.
- Clean the wall heaters and inspect air returns/LPG Heater vents on outside of trailer
- Inspect air returns and LPG Heater intake/exhaust vents for anything that would impede airflow.
- Operate the power vents to confirm cover is open and filter is clean for proper operation.
- Operate the A/C unit to confirm the filters and coils are clean and unit is cooling appropriately. Inspect all toilets, shower, sinks, and floor drains for proper operation.
- Inspect handicap accessible features: shower grip tape, shower wand, seating and all grab bars
- Inspect showers for cracks or user damage.
- Inspect all water connections in utility room for any signs of leakage.
- Check to make sure flooring is dry and clear of any debris and empty trash cans.
- Verify smoke/CO2 detector is operating.
- Immediately advise management of issues, and take steps to stop use.

INSTRUCTIONS/PRECAUTIONS

- Empty All Tanks Before Transporting trailer.
- Danger: Make sure steps clamps and pins are installed before use.
- Read and understand entire complete manual before use.
- Keep water in sink traps and toilet bowls to keep smell out of trailer.
- Use RV chemical to treat waste tank after each pump out.
- To keep waste tank clean: Pump waste tank using 2" wand thru toilets and suck solids off top first and work your way to the bottom of the tank, repeat for each tank (some trailers have two tanks tied together).
- Hands free faucets require battery replacement at least yearly.
- During freezing conditions: Flush with RV antifreeze then blow out before freezing conditions. Follow flushing directions for water heaters.
- Clean Hose, faucet, showerhead and water heater screens monthly.
- Wash and wax exterior regularly. Check lug nuts and air pressure in tires daily.
- Lock all doors and close toilet lids before transporting.
- A/C, Toilet and Faucets, etc carry a 1 or 3 year warrantee thru the Mfg.
- Check for leaks daily to avoid water damage.
- Inspect and replace caulk and paint regularly to avoid damage.
- Tankless Water Heaters, if equipped: If they don't stay on, they may have air in gas line, see its manual on how to purge the gas line of air.
 - For Toilet or A/C Service call Dometic at 877-898-7091

SAFE TRAILERING

CLEARANCE - 11' 3" Follow These directives

Do Not tow with full waste tanks

- Check lug nuts before travel
- Frequently check tire pressure and tread wear
- Check all exterior lights for operation
- Check trailer brakes before pulling onto roadway
- Stay within your vehicles towing capacity
- Secure interior items: partition doors, cabinet doors, cargo, & lights turned off
- Secure exterior items: steps locked, propane
- tanks secured, awning locked, & doors locked
- On lowering trailer: check hitch pins on axles,
- and straps on lowering box
- Secure the coupler
- Chock Tires before unhooking trailer
- Cross and hook the safety chains

KNOW THE TYPE GAS REQUIRED FOR ALL **APPLIANCES IN YOUR TRAILER BEFORE OPERATING (PROPANE(LP) OR NATURAL GAS(NG))**

Notice: Before turning on gas (NG or LP), make certain all gas connections have been made tight, all appliance valves are turned off, and any unconnected outlets are capped. After turning on gas, test gas piping and connections to appliances for leakage with a soapy water or bubble solution and light all pilots if equipped.

Before Turning on LP gas be certain appliances are designed for LP gas and are equipped with the correct orifices. Securely cap this inlet when not in use. Regulator must be rated for at least 500,000BTU.

FOR OPTIMUM **AIR CONDITIONER** 0 PERATIO

Temp set to medium (not full cold) - AC fan speed to high If you experience loss of cold air or "icing", turn off the AC by setting the fan speed to high (not AC high) Run the unit for 1-2 hours on fan only, then return to AC.

FOR YOUR SAFETY All Heater and Laundry Exterior Fresh Air and Exhaust Vents Must Be Inspected and Cleaned Daily

